

WIRING DIAGRAM FOR STRAT®



Directions: Tie white & green wires together (Ground) and solder to volume pot. Take orange wires (hot) and connect to switch where noted by blue arrows.

Note: All Lead wires are on the same side as the high "E" lead string.

250K pots recommended for better tone.
.022mfd cap recommended

FOR FOLLOWING SINGLE COIL PICKUPS
LACE SENSOR GOLD, RED, BLUE, SILVER
HG -1000, HG - 1500
LACE TRANSENSOR
LACE CALIFORNIA
HOT GOLD
ALL CUSTOM SHOP "SENSOR'S"

