

Übersicht YAMAHA PSR-Serie

PSR	Jahr	Tasten	Anschl. Dynam.	Panel Voices	XG Voices	Polyph	Styles	Demos	Reverb	Chorus	DSP	Harmony	Dual	Split	Anschlüsse		
															MIDI	To Host	USB
200	1991	61		100		?	50	15	*					*			
300	1991	61	*	100		?	50	15	*				*	*	*		
210	1993	61	*	100		28	50	15	*			6	*	*			
310	1993	61	*	100		28	100	15	*			6	*	*	*		
220	1995	61	*	100		28	100		*				*	*	*		
230	1995	61	*	100		28	100		*				*	*	*		
320	1995	61	*	128		28	100	8					*	*	*		
420	1995	61	*	128		28	100	8					*	*	*		
225	1998	61	*	100		32	100	3	8	4	33	26	*	*	*		
240	1999	61	*	100		16	100	100					*	*	*		
260	2000	61	*	100		16	100						*	*	*		
270	1999	61	*	128		32	100		8	4	33	26	*	*	*		
275	2003	61	*	108	360	32	100		9	4		26	*	*	*		
290	2002	61	*	108	480	32	135		8	4	38	26	*	*	*		
295	2004	61	*	114	359	32	135		9	4		26	*	*	USB		
330	1997	61	*	128		31	100	20	9			25	*	*	*		
400	1991	61	*	128		28	101	3	*			*			*		
500	1991	61	*	128		28	103	3	*		2	*		*	*		
600	1992	61	*	100		28	103	3	*			*	*	*	*		
410	1993	61	*	128		28	80	5				10		*	*		
510	1993	61	*	128		28	103	6			8	10		*	*		
520	1995	61	*	141		32	100	25	12	9	45	22	*	*	*		
620	1995	61	*	141		28	100	25	12	9	45	22	*	*	*		

PSR	Jahr	Tasten	Anschl. Dynam.	Panel Voices	XG Voices	Polyph	Styles	Demos	Reverb	Chorus	DSP	Harmony	Dual	Split	Anschlüsse		
															MIDI	To Host	USB
340	1999	61	*	100		32	100	3	8	4	33	26	*	*	*		
350	2001	61	*	116	Expand	32	106		8		38	26			*		
450	2004	61	*	135	480	32	140		12	6	39	26		*	*		
550	2001	61	*	219	480	32	112	9	24	16	74	22	*	*	*		
530	1997	61	*	200	480	32	100	12	13	10	46	16	*	*	*	*	
540	1999	61	*	215	480	32	106	5	24	16	74	22	*	*	*	*	
630	1997	61	*	215	480	32	100	15	13	10	46	16	*	*	*	*	
730	1997	61	*	200	480	64	100	15	13	10	46	16	*	*	*	*	
640	1999	61	*	223	480	32	160	8	24	16	74	22	*	*	*	*	
740	1999	61	*	267	480	64	160	10	24	20	102	22	*	*	*	*	
1000	2001	61	*	233	480	32	169		23+3	15+3	93+3				*	*	
1100	2003	61	*	287	480	32	181		23+3	15+3	92+3				*		*
1500	2004	61	*	297	480	96	190	5	35+3	30+3	289+13				*		*
2000	2001	61	*	313	480	64	181		29+3	25+3	252+13	49+10			*	*	
2100	2003	61	*	338	480	64	197		29+3	25+3	252+13	49+10			*		*
3000	2004	61	*	332	480	128	240	5	35+3	30+3	298+13	61+10			*		*
4000	1995	61	*	367		32	120	14	16	10	50	16	*	*	*		
6000	1994	61	*	128		38	50	21	23	9		16	*	*	*		
7000	1995	61	*	473		64	120	14	16	10	56	16	*	*	*		
8000	1997	61	*	261	480	64	214	21	24+3	20+3	78+10	50+3	*	*	*		
9000	1999	61	*	331	480	126	125		29+3	25+3	164+10	17	*	*	*		

PSR	Jahr	Tasten	Anschl. Dynam.	Panel Voices	XG Voices	Polyph	Styles	Demos	Reverb	Chorus	DSP	Harmony	Dual	Split	Anschlüsse MIDI To Host USB		
E203	2005	61		129		32	102		9							*	
E213	2007	61		129	233	32	102		9							*	
E303	2005	61	*	108	359	32	106		9	4		26	*	*		*	
E313	2007	61	*	108	359	32	106		9	4		26	*	*		*	
E403	2006	61	*	116	361	32	155		9	4		26	*	*		*	
E413	2007	61	*	116	361	32	165		9	4		26	*	*		*	
DJX	1998	61	*	140	128 (GM)	32	100	3	8	4	33					*	
DJX II	2000	61		203	180 (alt.)	32			11	7						*	
EZ-200	2007	61	*	1	361	32	100		9							*	
S500	2006	61	*	283	361	32	150		25	30	178	26	*	*	USB		*
S550	2008	61	*	294	480	64	176		35	44	237	26	*	*	USB		*
S700	2007	61	*	317	480	96	205		34+3	29+3	297+13		*	*	*	*	*
S900	2007	61	*	392	480	128	305		34+3	29+3	297+13	60+10	*	*	*	*	*
3500	1989	61	?	100			100						*	*		*	
4500	1989	61	*	100			100						*	*		*	
4600	1990	61	*	100			100		3				*	*		*	
5700	1993	61	*	100		38	36	4	3	9		16				*	
6700	1991	76	*	100		40	36	2	25	8		16				*	
1700	1994	61	*	128		28	100	8			8	10		*		*	
2700	1994	61	*	128		28	100	8			8	10		*		*	

Detailliertere Angaben in den YAMAHA-Handbüchern unter <http://www.yamaha.co.jp/manual/german/index.php>

Weitere Info's auch unter http://www.synrise.de/docs/types/y/yamaha/yamaha_psr-serie.htm

PSR	One Touch Setting	Registration Memory	Virtual Arranger	Groove & Dynamics	Music DB	Drum Pads	Multi Pads	Pitch Bend	Modu- lation	Guide LED's	Cartridge	Floppy Disk	Ausgangsleistung Netz/ Batteriebetrieb
200													2x2W
300													2x2W
210													2x2W
310													2x2W
220													2x3/ 2x6W
230										*	*		2x3/ 2x6W
320	*						11 x 4				*		2x6W/ 2x4,5W
420	*						14 x 4			*	*		2x6W/ 2x4,5W
225	*												2x3W
240	*												2x2W
260	*						10 x 4						2x2W
270	*												2x3W
275													2x2,7W
290	*				208								2x3W
295		8 x 2											2x3W
330	*						26 x 4				*		2x6W/ 2x5,5W
400						4		*					2x8W/ 2x4W
500							4	*					2x8W/ 2x4W
600							4	*				*	2x8W/ 2x4W
410	*						4	*					2x4,5W/ 2x1,5W
510	*						4	*					2x4,5W/ 2x1,5W
520	*	8 x 4					21 x 4	*			*		2x6W/ 2x4,5W
620	*	8 x 4					21 x 4	*			*	*	2x6W/ 2x4,5W

PSR	One Touch Setting	Registration Memory	Virtual Arranger	Groove & Dynamics	Music DB	Drum Pads	Multi Pads	Pitch Bend	Modu- lation	Guide LED's	Cartridge	Floppy Disk	Ausgangsleistung Netz/ Batteriebetrieb
340	*											*	2x6W
350					208		9 x 4					*	2x3W
450	*				227			*				*	2x6W
550		8 x 4			220		10 x 4	*				*	2x6W/ 2x4,5W
530	*	8 x 4	*				9 x 4	*			*		2x6W/ 2x4W
540		8 x 4					9 x 4	*				*	2x6W/ 2x4,5W
630		8 x 4	*				9 x 4	*				*	2x6W/ 2x4W
730		8 x 4	*	49/25/17			9 x 4	*	*			*	2x6W/ 2x4W
640		8 x 4					9 x 4	*				*	2x6W
740		8 x 4		11/ 18			9 x 4	*	*			*	2x6W
1000								*				*	2x12W
1100							54 x 4	*				*	2x12W
1500	*						54 x 4	*	*			*	2x12W
2000							54 x 4	*	*			*	2x12W
2100							54 x 4	*	*			*	2x12W
3000	*						80 x 4	*	*			*	2x12W
4000	*	16x8					8	*	*			*	2x9W
6000	*	4x8					80 x 4					*	2x12W
7000	*	16x8					8	*	*			*	2x20W
8000	*	16x8					50 x 4	*	*				2x20W
9000	*	64x8			616		60 x 4	*	*			*	2x28W

PSR	One Touch Setting	Registration Memory	Virtual Arranger	Groove & Dynamics	Music DB	Drum Pads	Multi Pads	Pitch Bend	Modu- lation	Guide LED's	Cartridge	Floppy Disk	Ausgangsleistung Netz/ Batteriebetrieb
E203													2x2,5W
E213													2x2,5W
E303													2x2,5W
E313													2x2,5W
E403		8x2			256			*					2x2,5W
E413		8x2			300			*					2x2,5W
DJX													2x6W
DJX II													2x6W
EZ-200										*			2x2,5W
S500		8x8			500			*			USB-Flash		2x12W
S550		8x8			600			*			USB-Flash		2x12W
S700		8			Music Finder		80 x 4						2x12W
S900		8			Music Finder		95 x 4						2x12W
3500		2				6		*	*				2x8W
4500		4				8		*	*				2x8W
4600		4				8		*	*				2x8W
5700		10/ 16					8	*	*			*	2x10W
6700		10/ 16						*	*			*	2x10W
1700	*	8						*	*			*	2x8W
2700	*	8				4	4	*	*			*	2x8W

PSR	Maße (mm)	Gewicht	Empfohlene Netzteile											Bemerkung
			PA-3	PA-3B	PA-3C	PA-4	PA-5	PA-5B	PA-5C	PA-5D	PA-6	PA-7	PA-40	
200	931x347x137	4,70 kg	*			*							*	PSR 200 Schwestermodell
300	931x347x137	4,70 kg	*			*							*	
210	908x344x110	5,10 kg	*			*							*	PSR 210 Schwestermodell
310	908x344x110	5,10 kg	*			*							*	
220	933x372x126	7,00 kg	*	*										PSR 220 Schwestermodell
230	933x372x126	7,10 kg	*	*										
320	933x372x127	5,90 kg					*	*	*					PSR 320 Schwestermodell
420	933x372x127	6,10 kg					*	*	*					
225	933x370x129	5,50 kg		*										PSR 225 Schwestermodell
240	933x370x129	5,70 kg		*										
260	933x370x129	5,20 kg		*										PSR 260 Schwestermodell
270	933x370x129	5,70 kg		*										
275	933x370x129	5,30 kg			*									PSR 275 Schwestermodell
290	952x389x140	6,80 kg		*	*									
295	952x388x146	7,00 kg			*									PSR 295 Schwestermodell
330	933x372x128	5,90 kg					*	*	*					
400	968x405x136	6,30 kg					*							PSR 400 Schwestermodell
500	968x405x136	6,30 kg					*							
600	968x404x136	6,80 kg					*							PSR 600 Schwestermodell
410	939x397x113	6,00 kg	*			*	*	*					*	
510	939x397x113	6,00 kg	*			*	*	*					*	PSR 410 Schwestermodell
520	973x397x146	7,40 kg					*	*	*					
620	973x397x146	7,80 kg					*	*	*					PSR 520 Schwestermodell

PSR	Maße (mm)	Gewicht	Empfohlene Netzteile											Bemerkung
			PA-3	PA-3B	PA-3C	PA-4	PA-5	PA-5B	PA-5C	PA-5D	PA-6	PA-7	PA-40	
340	952x387x170	7,8						*	*					
350	952x387x169	8,50 kg							*					
450	952x387x169	8,50 kg								*				
550	952x387x169	8,70 kg									*			PSR 450 Schwestermodell
530	952x387x147	8,00 kg									*			
540	952x387x169	8,70 kg									*			
630	973x397x155	9,50 kg									*			
730	973x397x155	9,50 kg									*			PSR 630 Schwestermodell
640	973x399x161	10,00 kg									*			
740	973x399x161	10,20 kg									*			PSR 640 Schwestermodell
1000	973x399x161	10,00 kg	PA-300 im Lieferumfang											
1100	973x399x161	10,00 kg	PA-300 im Lieferumfang											
1500	973x399x167	10,00 kg												
2000	973x399x161	10,50 kg	PA-300 im Lieferumfang											PSR 1000 Schwestermodell
2100	973x399x161	10,50 kg	PA-300 im Lieferumfang											PSR 1100 Schwestermodell
3000	973x399x167	11,00 kg												PSR 1500 Schwestermodell
4000	1058x446x176	12												
6000	1067x410x182	15												
7000	1058x446x178	14,5												
8000	1058x446x178	16												Sampling mit 44.1 kHz
9000	1114x465x183	22,5												

PSR	Maße (mm)	Gewicht	Empfohlene Netzteile											Bemerkung
			PA-3	PA-3B	PA-3C	PA-4	PA-5	PA-5B	PA-5C	PA-5D	PA-6	PA-7	PA-40	
E203	945x348x110	4,4		*	*									
E213	945x348x110	4,4		*	*									
E303	945x370x128	4,9		*	*									
E313	945x370x128	4,9		*	*									Flash Memory+Style Reg.
E403	952x388x146	7			*									
E413	946x402x136	7			*									
DJX	933x370x138	6,8						*	*					
DJX II	933x370x129	6,7						*	*					
EZ-200	945x348x110	4,7			*									
S500	946x402x130	7,5												PA-301, PA-300
S550	946x402x130	7,5												PA-301, PA-300
S700	1003x433x148	11,5												PA-300, PA-300B
S900	1003x433x148	11,5												PA-300, PA-300B
3500	1221x393x146	8,4				*							*	
4500	1221x393x146	8,8					*							
4600	1221x393x146	8,8					*							
5700	1067x409x160	15												
6700	1210x405x132	24												
1700	1045x412x164	12												
2700	1045x412x164	12												