

Line 6 Monkey - v1.67

Welcome, willc! [Logout](#) [MyAccount](#)

There are updates available for your POD HD500X.
Use the 'Updates' tab below to see what updates are available.

POD HD500X (Not Connected)

Connection: None
ESN: Unknown
[Connect To Device...](#)



Updates

Item	Installed	Newest
Driver		
⚠ Drivers	No	4.2.7.1
Device Firmware		
Ⓜ USB Firmware	-	1.01
Ⓜ Flash Memory	-	1.30
Applications		
✔ Line 6 Monkey	1.67	1.67
Ⓜ POD HD500X Edit	No	2.23
Ⓜ Workbench HD	No	2.10

[Update Selection](#)

Help and Info:
Clicking the 'Update Selection' button will update this selected item.
This driver adds support for the POD HD Pro X.

[Support...](#) [Quit](#)

Line 6 Monkey - Choose Device

Choose which device you would like to connect to and click OK:

Device	Connection	MIDI In	MIDI Out
POD X3 Live	USB		

If the device you are trying to connect to does not appear in the list, make sure the device is powered on and the cables between your PC and the device are connected.

If you still don't see your device, click here:
[I don't see my device...](#)

[OK](#) [Cancel](#)

Line 6 Monkey - No Devices Detected

If you are trying to connect to your Line 6 device using a USB cable directly from your computer to the device, an undetected device may be caused by:

- USB cable connection problem
- Device has a power switch and it is not turned on
- The device requires a USB driver and it is not installed

If you suspect you need to install or update the USB driver, choose which device you intend to connect to from the drop-down list below and click OK. Line 6 Monkey can assist you in downloading and installing the latest USB driver for this device.

Bass PODxt

If you are trying to connect to your Line 6 device using the standard MIDI ports on the device, check all MIDI cables and make sure the device is powered on. Then click below to establish communication with the device:

[Connect Using MIDI Cables...](#)

[OK](#) [Cancel](#)

Line 6 Monkey - No Devices Detected

If you are trying to connect to your Line 6 device using a USB cable directly from your computer to the device, an undetected device may be caused by:

- USB cable connection problem
- Device has a power switch and it is not turned on
- The device requires a USB driver and it is not installed

If you suspect you need to install or update the USB driver, choose which device you intend to connect to from the drop-down list below and click OK. Line 6 Monkey can assist you in downloading and installing the latest USB driver for this device.

- Bass PODxt
- Bass PODxt
- Bass PODxt Live
- Bass PODxt Pro
- GuitarPort
- GX
- KB37
- POD HD
- POD HD Pro
- POD HD Pro X
- POD HD300
- POD HD400
- POD HD500
- POD HD500X

If you are trying to connect the device, check all MIDI ports below to establish communication.

standard MIDI ports on the device are powered on. Then click OK.