

WMS470 Frequency Chart



Band M 826.300 to 831.900 MHz

Description	Full Range	Full Range	Full Range	Full Range
Group:	00	01	02	03
Frequency 1	826,300	826,300	826,300	826,300
Frequency 2	828,800	827,550	829,500	828,700
Frequency 3	830,550	829,300	830,500	827,700
Frequency 4	831,800	831,800	831,900	831,900
Frequency 5	826,800	828,550	826,700	826,900
Frequency 6	829,550	831,300	828,300	829,900
Frequency 7			831,300	831,500
Frequency 8				
Frequency 9				
Frequency 10				
Frequency 11				
Frequency 12				
Frequency 13				
Frequency 14				
Frequency 15				
Frequency 16				